



## WITHIN OUR GRASP TO BUILD YOUR DREAM PERFORMANCE MACHINE

### QUICK SHIFTER

The Dynojet Quick Shifter allows full throttle, clutchless shifting. This done by momentarily cutting the fuel and and ignition, which unloads the transmission. During this time, the rider can shift up to the next gear without rolling off the throttle or using the clutch.

### AUTOTUNE

The Autotune Kit comes with a wideband O2 sensor and controller that connects to the Power Commander V. With this kit, the power commander V automatically adjusts the fuel map while riding.

### COLOR LCD UNIT

The color LCD Unit connects to the Power Commander V via a "quick disconnect" cable. It is designed to remain on the bike and is weather resistant. While connected, the unit will display all available data from the Power Commander.

### MAP SELECTION FUNCTION

SHOWN WITH OPTIONAL MAP SWITCH AND BRACKET  
The Map Selection Switch between two different maps "on the fly" without the Power Commander V.

### SPEED/GEAR INPUT

Fuel and ignition timing\* adjustments can be made based on gear position or speed.

### ANALOG INPUT

The Allows user to make adjustments based on any 0-5 volt signal. Can be used for boost input, temperature input etc.

\*Not Available on all models. May require option Dynojet Ignition Module.



Team HKL Racing | Blk 1008 #01-16, Bukit Merah Lane 3 | Singapore 159721  
Tel: 6278 1268 | Email: enquiry@teamhklracing.com | www.teamhklracing.com